

## PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF TPM PRODUCTS, INC. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF TPM PRODUCTS, INC. IS STRICTLY PROHIBITED.

## INSTRUCTIONS:

- These dimensions represent actual brake kit so make sure the print out is 1:1 scale.
  You may have to adjust the printing scale of your printer to 103% for the true dimensions
  Cut out the template and glue to a rigid carborad.
  Place the carboard agsinst the corner of wheel hub center hole.
  A minimum of 3mm clearance is recommended for the wheel barrel and spoke.

## RB PERFORMANCE BRAKES FULLERTON, CA 92831

TITLE: Porsche 996/997 CCM (394)

DWG#: 2C22

Date Issued MM [IN] 3/14/16